

# **BEX**<sup>®</sup> Total Access



## **Features and Benefits**



Raised iconography on main console controls



Colour contrasted belt and deck



Laser cut numbers for easy seat positioning



Colour contrasted easy access handlebars



Raised weight stack numbering



Large locking foot pedals for mounting/dismounting



One handed locking seat adjustment



Range of movement adjustment



Twist select low increment weights



Handle start height adjustment



Large seat base for stability



Large print and graphic exercise instructions



### **Treadmill | Model 750T IFI**

#### **Features**

- Multiple belt logos ensure that one logo is always completely visible at all times so that visually impaired and other users can recognise if the belt is moving.
- Raised console iconography and colour allows easy identification of the main controls both by colour, large buttons and text for older users, plus raised iconography for visually impaired users.
- Emergency stop lanyard provides safe emergency stop for users with limited upper limb function.
- Running deck and belt colour contrast. This allows users to safely differentiate between the moving and non moving parts of the treadmill from the static side rails.





Raised console iconography



Multiple belt logos



**Emergency stop lanyard** 



Colour contrasted deck & belt

#### **Specifications**

Model Number: 750T IFI

**Speed Range:** 0.5 mph to 15.6 mph

(0.8kph to 25kph)

Elevation Range: -3% to 15% Running Surface: 22" × 62"

 $(56 \text{ cm} \times 157 \text{ cm})$ 

**Dimensions:**  $80'' L \times 34'' W \times 62.5'' H$ 

 $(204 \text{ cm} \times 86 \text{ cm} \times 159 \text{ cm})$ 

Maximum User Weight: 400 Lbs. (181 kg)

<sup>\*</sup>Step available in the U.K. only

# Treadmill | Model 750T IFI







### **Arc Trainer | Model 750AT IFI**

#### **Features**

- Locking mechanism for foot pedals provides complete stability for users when stepping on and off the equipment.
- Static side handles offer added stability when mounting, dismounting and exercising.
- Raised console iconography and colour allows easy identification of the main controls both by colour, large buttons and text for older users, plus raised iconography for visually impaired users.
- Large colour contrasted foot pedals and handles ensure easy identification when mounting and dismounting.





Raised console iconography



Foot pedal locking mechanism



Static side handles



**Colour contrasted foot pedals** 

#### **Specifications**

**Model Number:** 750AT IFI **Resistance:** 20 to 900 watts **Stride Length:** 24" (61 cm)

**Incline Levels: 21** 

**Dimensions:** 77" L  $\times$  62.5" H  $\times$  36.75" W at upper hand grips; 28.5" at base (196 cm  $\times$  159 cm  $\times$  93 cm; 72 cm)

Maximum User Weight: 400 lbs. (181 kg)

# **Arc Trainer | Model 750AT IFI**







### **Upright Bike** | Model 750C IFI

#### **Features**

- Raised console iconography and colour allows easy identification of the main controls both by colour, large buttons and text for older users, plus raised iconography for visually impaired users.
- Colour contrasted handlebar grips offer ease of identification and support when mounting and dismounting.
- Single handed central height adjustment for saddle allows users to adjust saddle height with either hand.
- Unicam pedals with heel straps prevent user's feet from slipping off pedals.
- Seat post positions have large text and raised iconography numbers for easy and quick seat positioning.





Raised console iconography



Colour contrasted handlebars



Central adjustment for saddle



Unicam pedals with heel straps

### **Specifications**


Model Number: 750C IFI Resistance: 20 to 900 watts Dimensions: 48" L  $\times$  23" W  $\times$  61" H

 $(122 \text{ cm} \times 58 \text{ cm} \times 155 \text{ cm})$ 

Maximum User Weight: 400 lbs. (181 kg)

<sup>\*</sup>Step available in the U.K. only

# **Upright Bike | Model 750C IFI**







### Recumbent Bike | Model 750R IFI

#### **Features**

- Single handed central seat position adjustment allows users to adjust seat position with either hand.
- Easy access side handles below seat height for ease of transfer.
- Step through design.
- Raised console iconography and colour allows easy identification of the main controls both by colour, large buttons and text for older users, plus raised iconography for visually impaired users.
- Unicam pedals with heel straps prevents user's feet from slipping off pedals.
- Raised iconography on seat adjustments. Seat carriage positions have large text and raised iconography numbers for easy and quick seat positioning.
- Colour contrasted handlebar grips offer ease of identification and support when mounting and dismounting.





Raised console iconography





Central seat adjustment



Unicam pedals with heel straps

#### **Specifications**

**Model Number:** 750R IFI **Resistance:** 20 to 900 watts

**Dimensions:** 63.5" L × 25" W × 49.5" H

 $(161 \text{ cm} \times 64 \text{ cm} \times 126 \text{ cm})$ 

Maximum User Weight: 400 lbs. (181 kg)

# Recumbent Bike | Model 750R IFI







### Lat Pull | Model 14130

#### **Features**

- Bar handle height adjustment. This lever operated single arm handle height adjustment allows the bar to be adjusted for shorter and wheelchair users down to 1400 mm start height from a seated position.
- Adjustable knee restraint and seat height allows shorter users and others with reduced trunk stability to maintain full flat foot contact with the floor. This permits correct pelvic positioning and avoids a round back during exercise.
- Instructions at seated user height ensure ease of reading from a seated position by all users including wheelchair users.
- Raised numbering with large fonts facilitates easy adjustment for older or visually impaired users.
- User accessible weight stack offers ease of weight selection from seated exercise position.
- Weight stack with low start weight and integral three-position twist select systems offering 2.5 kg increments is suitable for inexperienced and older users.



Bar handle height adjustment



**Raised numbering** 



Adjustable knee restraint



Instructions at seated height



#### **Specifications**

Model Number: 14130

Standard Stack: 245 lbs. (111 kg) Heavy Stack: 305 lbs. (138 kg)

**Dimensions:** 55.38" L × 55.25" W × 90.75" H

 $(141 \text{ cm} \times 140 \text{ cm} \times 231 \text{ cm})$ 

# Lat Pull | Model 14130







### **Chest Press** | Model 14000

#### **Features**

- Locking plunger adjustment on swing away seat allows easy access for wheelchair users and one-handed seat adjustment for users with limited mobility.
- Adjustable input arm enables a non-stressed start position for users with limited shoulder flexibility and wheelchairs users.
- Upright seat back support (10°) allows wheelchair users to maintain stability with heavier weights.
- User accessible weight stack offers ease of weight selection from seated exercise position.
- Weight stack with low start weight and integral threeposition twist select systems offering 2.5 kg increments is suitable for inexperienced and older users.
- Top mounted exercise pivot position ensures correct biomechanical chest press movement from the hinged lever arm pivoting at the top.
- Choice of upper and lower handle positions caters for wheelchair users, shorter users and those with reduced balance.





**Upright seat back support** 



Twist select



Adjustable input arm



Locking plunger adjustment

### **Specifications**

Model Number: 14000

Standard Stack: 245 lbs. (111 kg) Heavy Stack: 305 lbs. (138 kg)

**Dimensions:** 59.5" L × 43.25" W × 68.63" H

 $(151 \text{ cm} \times 110 \text{ cm} \times 174 \text{ cm})$ 

## **Chest Press | Model 14000**







### Overhead Press | Model 14010

#### **Features**

- Swing away seat with locking plunger adjustment allows easy access for wheelchair users and one-handed seat adjustment for users with limited mobility.
- Choice of upper and lower handle positions caters for wheelchair users, shorter users and those with reduced balance.
- Counterbalanced input arm with 2.5 kg start weight. This allows all users a light start weight for single arm (unilateral) use benefiting inexperienced and disabled users, including amputees and people who have had a stroke.
- Large type instructions with clear fonts, including written and graphic instructions, to suit all users.
- User accessible weight stack offers ease of weight selection from seated exercise position.
- Weight stack with low start weight and integral threeposition twist select systems offering 2.5 kg increments is suitable for inexperienced and older users.
- Raised weight stack iconography for visually impaired users to identify weight stack positions.



Counterbalanced input arm



Choice of handle positions

Large type instructions



Locking plunger adjustment



### **Specifications**

Model Number: 14010

**Standard Stack:** 165 lbs. (75 kg) **Heavy Stack:** 205 lbs. (93 kg)

**Dimensions:** 63.75" L × 59.38" W × 63.88" H

 $(162 \text{ cm} \times 151 \text{ cm} \times 162 \text{ cm})$ 



# Overhead Press | Model 14010







### Row | Model 14030

#### **Features**

- Choice of upper and lower handle positions caters for wheelchair users who cannot adjust seat height, shorter users and those with reduced balance, who can then maintain full foot contact with the floor.
- Eight position reversible chest pad ensures a full range of movement is achieved by both tall and short users.
- Large seat base offers more stability and confidence for older users as well as those with reduced trunk stability.
- Top mounted input arm pivot position maintains the natural body movement of a gradually descending hand position during the movement.
- User accessible weight stack offers ease of weight selection from seated exercise position.
- Weight stack with low start weight and integral threeposition twist select systems offering 2.5 kg increments is suitable for inexperienced and older users.



**Choice of handle positions** 



Large seat base



Top mounted input arm pivot



8 position reversible chest pad



#### **Specifications**

Model Number: 14030

**Standard Stack:** 245 lbs. (111 kg) **Heavy Stack:** 305 lbs. (138 kg)

**Dimensions:** 51.25" L × 45.5" W × 76" H

 $(130 \text{ cm} \times 116 \text{ cm} \times 193 \text{ cm})$ 

# Row | Model 14030







### Cable Column | Model 14220

#### **Features**

- Multi-function exerciser offering a very wide variety of exercises for all non-disabled and disabled users.
- Two large stability handles provide wheelchair and other users with the ability to stabilise when performing unilateral (single arm) exercises.
- Large type instructions with clear fonts, including graphic instructions to suit all users.
- Laser cut numbers on vertical height adjustment pole. The large numbers can be easily identified by visually impaired users.
- Low 2.5 kg start weights and 1.25 kg increments permit single arm exercise for users with stroke or other upper body impairment.
- Pistol grip height adjustment enables adjustment of start height with one hand, essential for amputees and stroke users.
- Integral 3-position twist select mechanism offers ease of weight selection from seated exercise position.



Large stability handles



Laser cut numbers



Height adjustment lever



Large type instructions



#### **Specifications**

Model Number: 14220

Standard Stack: 305 lbs. (138 kg) Dimensions:  $52'' L \times 43'' W \times 92'' H$  (132 cm  $\times$  110 cm  $\times$  233 cm)



## Cable Column | Model 14220







### Leg Curl | Model 14061

#### **Features**

- Five position adjustable calf pad accommodates different lower leg lengths.
- Large seat base facilitates easy transfer from a wheelchair.
- Thigh pad hold-down mechanism allows the thighs to be secured above the knee for reduced shear force on the knee joint while keeping it in a stable position.
- Raised numbers and large font on ROM. Start positions are easy to adjust/identify for visually impaired and older users.
- Start ROM on cam synchronised with user. Regardless of the starting position, the CYBEX patent pending ROM adjustment ensures the cam moves to maintain the correct strength profile for the user.
- User accessible weight stack offers ease of weight selection from seated exercise position.
- Weight stack with low start weight and integral three-position twist select systems offering 2.5 kg increments is suitable for inexperienced and older users.



Adjustable calf pad



Thigh pad clamping mechanism



Large seat base



Raised numbering



#### **Specifications**

Model Number: 14061

Standard Stack: 165 lbs. (75 kg) Heavy Stack: 205 lbs. (93 kg) Dimensions:  $56^{\circ}$  L  $\times$  39 $^{\circ}$  W  $\times$  64 $^{\circ}$  H

 $(142 \text{ cm} \times 99 \text{ cm} \times 162 \text{ cm})$ 



# Leg Curl | Model 14061







### **Leg Extension** | Model 14051

#### **Features**

- Sliding adjustment for tibia pad length. The tibia pads can be quickly and accurately positioned at the base of the shins without the need to screw or unscrew a lever.
- Spring loaded seat back adjustment lever which can be adjusted either from on or off the equipment. The push down lever is easy to operate for users with limited grip.
- Side handles parallel to seat side to assist with transfer.
- Raised numbers and large font on ROM. These make start positions easy to adjust and identify for visually impaired and older users.
- Large seat base facilitates easy transfer from a wheelchair.
- Start ROM on cam synchronised with user. Regardless of the starting position, the CYBEX patent pending ROM adjustment ensures the cam moves to maintain the correct strength profile for the user.
- User accessible weight stack offers ease of weight selection from seated exercise position.
- Weight stack with low start weight and integral three-position twist select systems offering 2.5 kg increments is suitable for inexperienced and older users.



Adjustment for tibia length pad



Side handles



Seat back adjustment lever



Raised numbering




#### **Specifications**

Model Number: 14051

Standard Stack: 245 lbs. (111 kg) Heavy Stack: 305 lbs. (138 kg) Dimensions: 49" L  $\times$  41" W  $\times$  64" H (124 cm  $\times$  104 cm  $\times$  162 cm)



# **Leg Extension | Model 14051**







### Leg Press | Model 14040

#### **Features**

- Centrally mounted seat adjustment with lever which can be easily operated with either right or left hand. No grip is required.
- Instructions at seated user height ensures ease of reading from a seated position by all users including those in wheelchairs.
- Large foot plate for stability when exercising.
- Laser cut numbering for seat adjustments, which can be viewed whilst seated. The large numbers are easily identified by visually impaired users.
- Side handles below seat height for ease of transfer.
- Large backrest and seat base offer more stability and confidence for older users as well as those with reduced balance.
- User accessible weight stack offers ease of weight selection from seated exercise position.
- Weight stack with low start weight and integral threeposition twist select systems offering 2.5 kg increments is suitable for inexperienced and older users.



**Central seat adjustment** 



Large foot plate



Instructions at seated height



Laser cut numbering



#### **Specifications**

Model Number: 14040

**Standard Stack:** 405 lbs. (184 kg) **Heavy Stack:** 505 lbs. (229 kg) **Dimensions:** 99" L  $\times$  41" W  $\times$  78" H (252 cm  $\times$  104 cm  $\times$  198 cm)



# Leg Press | Model 14040







# Total Access From CYBEX



We support you with the best value products which have been innovatively developed without compromising quality. Our comprehensive range of Stage 2 IFI accredited equipment can help your facility attract a huge diversity of customers.

Our forward thinking research and development means that our equipment is constantly evolving to not merely achieve but to exceed Inclusive Fitness Initiative (IFI) standards. By working with the IFI as a research partner and with disabled people to develop new equipment, we have a true understanding of the needs of the disabled population whether they have cognitive, sensory or physical impairments.

That said, our inclusive equipment is also appropriate and userfriendly for your non-disabled clients too. This ensures that you need only purchase one set of equipment and that all of your customers feel intergrated.

# \*This brochure is available in alternative formats at **www.cybexintl.com**

Boston ◆ New York ◆ Dubai ◆ London ◆ Hong Kong ◆ Hamburg NASDAQ: CYBI

CYBEX WORLD HEADQUARTERS

10 Trotter Drive • Medway • MA 02053 USA • T +1.508.533.4300 • F +1.508.533.5500

CYBEX INTERNATIONAL, UK LTD.

Oak Tree House • Atherstone Road • Measham • Derbyshire • DE12 7EL UK

T +44.845.606.0228 • F +44.845.606.0227

